XCANEX

Model: XC-1B



USER'S MANUAL ADDENDUM

piQx Imaging

TABLE OF CONTENTS

1. FLATPAGE 1

1.1 FLATPAGE ICONS 1
Single Page mode 1
Dual Page mode 1
1.2 POSITIONING THE BOOK 2
Single Page mode 2
Dual Page mode 2
1.3 USING FINGERS TO FLATTEN BOOK PAGES FOR DUAL PAGE MODE 3
1.3.1 Pages on thin side 3
1.3.2 Tightly bound books 3
1.4 SCANNING FULL BLEED PRINTED PAGES (E.G. MAGAZINES) 4
1.5 SCANNING PAGES WITHOUT FULL BLEED PRINTING (EDGE PRINTING) 4

FLATPAGE

1. FLATPAGE

FlatPage automatically corrects curved book pages into perfectly flat scans.
It is only applicable in Book Scanning mode.

1.1 FlatPage Icons

Single Page mode

Single Page mode

To go to dual page mode, click once and the icon becomes

It changes to
with another click.
A third click will bring it back to single page mode.

Dual Page mode



Scan from multiple books:
Books are of different widths and heights

Scan from single book

Dual Page mode
Scan from left to right page

Dual Page mode
Scan from right to left page

1.2 Positioning the Book

Single Page mode

You may follow the instructions in the User Manual Section 5.4, Positioning the Page.

Dual Page mode



8 ‘Document Detected

Indicators’ signify

that page has been successfully detected

Position the centre of the book’s gutter along the single-line guide in the centre of the screen.



Book is slanted



Book is misaligned

1.3 Using fingers to flatten book pages for Dual Page mode

1.3.1 Pages on thin side

1.3.2 Tightly bound books

Use your fingers to stretch out both sides of the book and hold it there.



Ensure that the wordings near the spine are clearly visible.



1.4 Scanning Full Bleed Printed Pages (e.g. Magazines)

This is not supported in FlatPage Dual Page Mode.

Please use Single Page mode and choose “Semi Auto Page Detection” for scanning full bleed printed pages.



Full bleed printed pages:
Pages that have printing all the way until the edges or gutter

For scanning full bleed printed pages, please select “Semi Auto Page Detection” (see User Manual Section 3.1 on “Scan Settings”) where the book gutter has to be manually adjusted to align to a guide

1.5 Scanning Pages without Full Bleed Printing (Edge Printing)



Pages without full bleed printing do not contain any form of printing around all 4 edges of each page as well as the gutter

You can scan books without edge-to-edge printing using FlatPage Dual Page mode.

FlatPage Dual Page mode only operates in “Auto Page detection”.

Under Dual Page mode, selection of “Semi Auto Page Detection” is disabled.

Similarly when “Semi Auto Page Detection” is selected in Book Scanning Mode, it is not possible to switch to Dual Page Mode.